

Daily Cleaning Manual

Ti-1

things to prepare before cleaning

- Kettle
- Bucket
- Toothbrush (or sharp brush)

Useful points for cleaning

- To enjoy your Sake, have the dispenser cleaned **at least once a week**. Otherwise, it will cause change in the taste of Sake and malfunction of the dispenser.
- Upon the cleaning, please have the lid and filter washed with hot water.



1.

Remove the Sake bottle from the bottle holder and wash the lid, cap, filter and bottle holder with hot water well.



2.

Dispense all the Sake left in the device with the same procedure as serving Sake. This Sake can be used for cooking as seasoning..



3.

Remove the server bottle holder from the unit and wash with hot water well.



4.

Feed water (approx.70°C) to the bottle holder to a degree not to cause overflow. **(Pay attention to HOT WATER !!)**



5.

Place the nozzle to the dispensing position to drain all the water left in the dispenser (approx. 3 liters)



6.

After draining all the hot water, gently scrub the sensor electrode at the nozzle end with a tooth brush and washing it well



7.

Wipe the machine with a cloth dipped in a neutral detergent solution or soap and water, then wipe it well with a dry cloth. Do not use paint thinner or other volatile fluids or alkaline detergents.



NOTICE!!

* First Sake dispensed from the unit might contain some water from cleaning. Please use the first feed Sake for cooking as seasoning.